



# REVIVE FURNITURE PAINT



## APPLICATION GUIDE

## Revive Furniture Paint

- Revive delivers an elegant satin finish with hard-wearing protection for furniture, cabinetry, doors and other woodwork.
- Built-in wax infusion for a smoother, more durable finish.
- No finish sealer or wax required.
- Ultra smooth, self-levelling to reduce brush marks.
- Washable - most household marks and stains easily wipe away.
- For interior and exterior use.
- Superior colour depth.
- High coverage.
- Easy to clean and dust.
- Low odour.
- Low VOC: Classified as low VOC by the Australian Paint Approval Scheme (APAS).

## Suitable Surfaces:

Suitable for bare, previously varnished, lacquered or painted furniture. Also suitable for doors, cabinetry, woodwork, skirting and trim.

## Colours:

There are twelve popular colours, factory tinted and ready to go.

Estimate your paint needs:

Revive Furniture Paint covers 12-14 square metres per litre.

**Helpful Hint:** *A 400ml jar holds enough paint, with two coats, for an area roughly the size of 40 x A4 pieces of paper.* Examples of projects that would require one 400ml jar: a pair of bedside tables with two drawers, a set of 6 stools, a double or queen bed frame, a dining table (for 6), a set of 6 dining chairs, or a chest of drawers or a cabinet.

Choose your tools:

All you need is some sandpaper and a good quality brush. To achieve a super smooth finish, it is important to choose the right brush. A general rule to follow - the larger the area, the wider the brush. A wider brush means fewer brush strokes, giving a smoother finish.

You may need several brushes in different widths for your project, and microfibre rollers are a perfect choice for large areas such as doors or tables. Use a fine/medium sandpaper sponge block.



## PREPARATION

### Clean & Prepare:

All pieces should be thoroughly cleaned to remove dust, dirt and grime, and if necessary, degreased. Lightly sand (see Helpful Hint\*) and wipe off dust with a damp cloth.

Optional – fill old holes and damaged areas with wood putty, following the manufacturer's directions.

For best results, prime before painting. After sanding, apply 1 coat of Porter's Prepare & Prime (a multi-surfaces primer and stain blocker). Allow to dry for 2 hours before applying the topcoat.

**\*Helpful Hint:** The timber used for furniture can contain a lot of tannins (especially very old pieces), which can bleed through and stain the final paint coat. Leave as much of the existing finish as you can, just scuff or lightly de-gloss the surface so that the primer, can adhere.

### PREPARING LAMINATE:

Step 1: Lightly sand the surface using 180 grit sandpaper to remove any sheen and create a key.

Step 2: Apply 2 coats of Dulux Precision® Maximum Strength Adhesion Primer, following the on-pack instructions. Allow 24 hours to dry and cure before overcoating with Porter's Revive.



## APPLICATION

### Application of paint:

#### **First Coat:**

Paint a thin coat in the direction of the grain of the wood, using long strokes. Paint from end to end. A microfibre roller can sometimes leave a subtle texture, which can be smoothed off by very lightly dragging a brush over at a low angle. Avoid short brush strokes, and repeatedly brushing back over the paint as it is drying, as this will cause stop/start marks and brushstroke texture.

Touch dry in 1 hour. Allow a minimum of 2 hours dry time before applying the second coat.

**Helpful Hint:** Revive Furniture Paint is formulated to be self-levelling for a smoother finish, but despite that it is still possible to create unwanted brush marks. The leading cause of brush marks is having too much paint loaded onto the brush. The brush should be dipped in halfway up the bristles, then the excess paint removed. Paint should be visible on the brush, but no paint should drip off.



## DRY TIMES, WASH UP & LIMITATIONS

### **Second Coat:**

Inspect your project and gently sand off any drips. For a super smooth end result, gently sand down any visible brushstrokes with a fine sandpaper sponge block. Wipe off any dust and apply a second coat as you did for the first coat, using long strokes and brushing from end to end to avoid start/stop marks.

Allow to dry for 8 hours. Full hardness takes around 7 days. Avoid very heavy use immediately after drying.

### **Wash Up:**

Water

### **Limitations:**

Do not apply in high humidity, below 10°C or above 30°C.

### **Help & Advice:**

AU: 1800 656 664 NZ: 0800 672 648



## SAFETY DIRECTIONS

### Safety Directions

May cause an allergic skin reaction. Keep out of reach of children. Avoid breathing dust, fume, gas, mist, vapours or spray. Contaminated work clothing should not be allowed out of the workplace. Wear protective gloves/protective clothing including eye/face protection. SPILLS & LEAKS: Slippery when spilt. Wear protective equipment. For liquids absorb with sand or soil. Collect and seal in properly labelled drums. Refer to local authority for disposal advice. FIRST AID: If poisoning occurs, contact a Doctor or Poisons Information Centre (Phone Australia 131 126; New Zealand 0800 764 766). If medical advice is needed, have product container or label at hand. SWALLOWED: If swallowed, do NOT induce vomiting. Give a glass of water. Seek medical advice. EYE: If in eyes, hold eyes open, rinse cautiously with water for at least 15 minutes and see a doctor. SKIN: If skin contact occurs, remove contaminated clothing and wash skin thoroughly. If irritation occurs seek medical advice. INHALED: Remove from contaminated area. DO NOT REUSE CONTAINER UNLESS THOROUGHLY DECONTAMINATED. EMERGENCY INFORMATION (ALL HOURS): AUST-1800 220 770 NZ-0800 220 770